

See all emulators




Seat occupancy sensor programs

BMW.....	4
FIAT.....	7
MAZDA.....	8
MERCEDES.....	9
MINI	18

[See all emulators](#)

Wiring colour codes



The LED behavior

- no jumpers – diagnostic mode - it flashes every second
 - adjusting to the ECU – flashing 0,1 sec
- after adjusting it lights constantly and blinks every other second

[See all emulators](#)

ATTENTION!!!

This emulator can only be used for testing purposes or to verify accurate functioning of the AirBag system.

This emulator cannot remain in your car as a replacement for new seat occupancy mat

The emulator needs to be connected to the plug under the passenger seat instead of original seat occupancy sensor.

There are 3 cables

+12V ACC	red
-----------------	------------

GND	blue
------------	-------------

Digital signal	green
-----------------------	--------------

Before connecting the emulator, use multimeter to check signals on pins in the plug!

[See all emulators](#)

BMW

No.	Model	Connector type	Year	
1	BMW Series 1 – E81	4-pin connector	2007-2010	OPEN
	BMW Series 3 – E90, E92, E93			
	BMW Series 5 – E60, E63, E64			
	BMW Series 7 – E65			
	BMW Series X – E70, E71			
2	BMW Series 1 – E87	4-pin connector	2003-2007	OPEN
	BMW Series 3 – E90	4-pin connector		
	BMW Series 5 – E60, E63	4-pin connector (2005-2007) 3-pin connector (2003-2005)		
	BMW Series 7 - E65	4-pin connector (2005-2007) 3-pin connector (2003-2005)		
	BMW Series 3 – E36, E46 BMW Series 5 – E39 BMW Series 7 – E38 BMW Series 8 – E31 BMW Series X – E53	3-pin connector	1997-2003	

[See all emulators](#)

No.1 BMW

USE

European models

(2007 – 2010)



BMW Series 1 – E81

BMW Series 3 – E90*, E92*, E93*

BMW Series 5 – E60, E63, E64

BMW Series 7 – E65

BMW Series X – E70, E71

Attention!

If still after installation of the emulator your car signalizes unfastened passanger seatbelt fault, put a resitor in place of the seatbelt sensor.

For E90, use 680-Ohm resistor

For E60, use 510-Ohm resistor

**If the Emulator doesn't adjust, swap green and blue wires in the Emulator's plug.*

[See all emulators](#)

No.2 BMW

USE

(2003 – 2007)

BMW Series 1 – E87

BMW Series 3 – E90*

BMW Series 5 – E60, E63

BMW Series 7 - E65



(1997 – 2003)

BMW Series 3 – E36, E46


BMW Series 5 – E39

BMW Series 7 – E38

BMW Series 8 – E31

BMW Series X – E53

Insert a 510-ohm resistor into the seat belt socket





**If the Emulator doesn't adjust, swap green and blue wires in the Emulator's plug.*

See all emulators

FIAT


No.	Use
1	Fiat Stilo



[See all emulators](#)

MAZDA

No.	Model
1	Mazda Premacy, MX-5, 626, 323, 6 GG/GY



[See all emulators](#)

MERCEDES

No.	Model	Year	
1	Mercedes E-class W211 (Temic Armada controller)	2004-2007	OPEN
	Mercedes E-class W211 (Bosch controller)	2002-2007	
	Mercedes C-class W203	2006-2007	
	Mercedes CLS-class W219	2005-2010	
	Mercedes CLK-class W209	2006-2009	
	Mercedes S-class W220	2002-2005	
	Mercedes S-class W221	2006	
2	Mercedes E-class W211 (Temic controller)	2004-2007	OPEN
	Mercedes SL-class W230	2004	
	Mercedes SLK-class W171	2004-2011	
3	Mercedes E-class W211 (Temic Armada controller)	2002-2003	OPEN
4	Mercedes E-class W211 with: <i>Temic controller no. 002 820 35 26</i> <i>Bosch controller no. 002 820 29 26; 0 285 001 441</i>	2002-2003	OPEN
5	Mercedes E-class W211 (Temic controller)	2002-2004	OPEN
	Mercedes S-class W220	2003-2005	
6	Mercedes E-class W210 (with airbag OFF indicator after lifting)	1999-2003	OPEN
	Mercedes Vito II W639	2002-2005	
	Mercedes ML-class W163	2000-	
	Mercedes A-class W168	2002-2005	
	Mercedes S-class W220	2002-2003	
	Mercedes C-class W203	-2005	
	Mercedes CLK-class W209	2002-	
	Mercedes Vaneo W414		

[See all emulators](#)

7	Mercedes A-class W168	1997-2001	<div>OPEN</div>
	Mercedes C-class W202	1999-2001	
	Mercedes Vito W638	-2003	
	Mercedes ML-class W163 (TRW controller)	1999	
	Mercedes E-class W210 (before lifting – with airbag OFF indicator)	-1999	
8	Mercedes E-Class W212	2009-2016	<div>OPEN</div>
	Mercedes E-Class S212/C207/A207	2013-2016	

[See all emulators](#)

No.1 Mercedes

USE

Mercedes E-Class W211 with Temic Armada controller (2004-2007)

Mercedes E-Class W211 with Bosch controller (2002-2007)

Mercedes C-Class W203 (2006-2007)

Mercedes CLS-Class W219 (2005-2010)

Mercedes CLK-Class W209 (2006-2009)

Mercedes S-Class W220 (2002-2005)

Mercedes S-Class W221 (2006)



Insert a 100-ohm resistor into the seat belt socket

[See all emulators](#)

No.2 Mercedes

USE

Mercedes E-Class W211 with Temic controller (2004-2007)

Mercedes SL-Class W230 (2004)

Mercedes SLK-Class W171 (2004-2011)



Insert a 100-ohm resistor into the seat belt socket

[See all emulators](#)

No.3 Mercedes

USE

Mercedes E-Class W211 with Temic Armada controller (2002-2003)



Insert a 100-ohm resistor into the seat belt socket

[See all emulators](#)

No.4 Mercedes

USE

Mercedes E-Class W211 (2002-2003)
with the following airbag control units:

—

Temic 002 820 35 26

Bosch 002 820 29 26; 0 285 001 441



Insert a 100-ohm resistor into the seat belt socket

[See all emulators](#)

No.5 Mercedes


USE

Mercedes E-Class W211 with Temic controller (2002-2004)

Mercedes S-Class W220 (2003-2005)



Insert a 100-ohm resistor into the seat belt socket



[See all emulators](#)

No.6 Mercedes





USE


Mercedes E-Class W210 after lifting-
 -with airbag OFF indicator(1999-2003)
Mercedes Vito II W639 (2002-2005)
Mercedes ML-Class W163 (2000-)
Mercedes A-Class W168 (2002-2005)
Mercedes S-Class W220 (2000-2003)
Mercedes C-Class W203 (-2005)
Mercedes CLK-Class W209 (2002-)
Mercedes Vaneo W414



Insert a 100-ohm resistor into the seat belt socket

Examples of connecting the emulator:



[See all emulators](#)

[See all emulators](#)




No.7 Mercedes

USE

Mercedes A-Class W168 (1997-2001)
Mercedes C-Class W202 (1999-2001)
Mercedes Vito W638 (-2003)
Mercedes ML-Class W163 with TRW controller (1999)
Mercedes E-Class W210 before lifting-
-with airbag OFF indicator (-1999)



Insert a 100-ohm resistor into the seat belt socket



After correctly connecting the emulator, the SRS/AIRBAG fault on the dashboard will turn off without the need to delete the fault code.

[See all emulators](#)

No.8 Mercedes

USE

Mercedes E-Class W212 (2009-2016)

Mercedes E-Class S212/C207/A207 (2013-2016)



Insert a 100-ohm resistor into the seat belt socket

[See all emulators](#)

MINI

No.	Model	Year
1	Mini Cooper	2002-2005



Insert a 680-ohm resistor into the seat belt socket

[See all emulators](#)

Warning!!!

Due to possible construction changes of cars, check signals with multimeter in the ECU plug.



All rights reserved.

Unauthorized copying, hiring, lending, public performance will be punished!

We state that we are the only authentic authors of this manual. We possess copyright of this publication. Any trials of unauthorized copying, hiring, quoting prohibited!!! Both service and advertisement constitute copyright and they are the subject to the protection in accordance with the Act from 4th Feb. 1994 on Copyright and Related Laws (Statute Book no. 24 position 93) and protection on the basis of the Act from 8th June 1993 on combating an unfair competition (Statute Book no. 47 position 211)

www.carlabimmo.com

Last updated 04.07.2024