

RENAULT ESL EMULATOR

Instruction manual

ESL/ELV REPLACING PROGRAM



Table of contents

Page 2	Program introduction	MIN. VERSION	РНОТО	PINOUT	VIDEO
Page 3	· Renault ESL 3	108	PHOIO	PINOUI	VIDEO
Page 4	· Renault ESL 2	108	o o		
Page 5	· Renault ESL 1	108	۵		
rage o	Reliadii ESE I	100			





Program introduction

Example cars

Renault

Captur Clio III Clio IV Espace IV (phase II) Espace IV (phase III) Fluence

Laguna II

Laguna II (lift 2004-2006)

Laguna III

Megane II (lift 2004-2006) Megane III (Scenic II Scenic III Talisman

Jumpers to solder

To choose the program you have to solder specific jumpers on the back of the Emulator:





2+3+4+5+6

ESL 2



1+2+3+4+5+6

ESL 3



1+3+4+5+6

If the Emulator doesn't work, solder an additional jumper CAN 120R



Renault ESL 3

Supported cars

Renault Laguna II (lift 2004-2006) Renault Megane II (lift 2004-2006) Renault Espace IV (2004-2006)





Disconnect plug from ESL








To choose the program you have to solder specific jumpers on the back of the Emulator:

1+3+4+5+6





3

Connect the Emulator to the ESL's plug according to the picture on the right.



(i)

Attention!

If SERVICE warning appears on the dashboard, cut the 100Ω resistor between pins 2 and 4 of the emulator's plug



Start the car.







End of the procedure



Renault ESL 2

Supported cars Renault Talisman Renault Captur Renault Clio IV Renault Megane III Renault Scenic III Renault Fluence

Renault Laguna III Renault Espace IV (phase III)





Disconnect plug from ESL







To choose the program you have to solder specific jumpers on the back of the Emulator:

1+2+3+4+5+6





3

Connect the Emulator to the ESL's plug according to the picture on the right.



(i)

Attention!

If SERVICE warning appears on the dashboard, cut the 100Ω resistor between pins 2 and 4 of the emulator's plug




4 ,

Start the car.







End of the procedure



Renault ESL 1

Supported cars
Renault Megane II
Renault Laguna II
Renault Scenic II
Renault Clio III
Renault Espace IV (phase II)





Disconnect plug from ESL







To choose the program you have to solder specific jumpers on the back of the Emulator:

2+3+4+5+6





3

Connect the Emulator to the ESL's plug according to the picture on the right.



(i)

Attention!

If SERVICE warning appears on the dashboard, cut the 100Ω resistor between pins 2 and 4 of the emulator's plug



Start the car.







End of the procedure